

Blocked Elevations Directions and Requirements

1. Copy your floor plan 4 times and rotate to draft each elevation.
2. Download the ***Blocking out your cottage elevations CAD reference file***. Find the outline of the elevations that you selected and copy and align them correctly with your rotated floor plan.
3. Show the outline of walls, door and window locations. (Put all elements of the correct layers.)
4. Show roof slope tags (1:4 MED Text)
5. Show overhangs and overhang dimensions. (1:4 MED Size)
6. Show decks, porches and steps.
7. Show the GRADE line with slight slopes at each end.
8. Show Foundation as necessary under the house, porch, decks and step areas.
9. Show elevation dimension heights on each elevation.
10. Title each elevation. (1:4 Title, Title Layer) under each elevation and note the SCALE: $\frac{1}{4}" = 1'-0"$ (1:4 Med, Notes Layer). Aligned to the left most part of the elevation.

Grading:

Do not print the drawings. This will be checked on your computer for a Formative Grade.



Standards:

Develop interior and exterior elevations (m6) Share files and documents (b2)