

## DREAM HOUSE CAD BLOCKED ELEVATIONS

1. Block out the 4 elevations of your house. Open up the AutoCAD file Y:\DOSSIN\ARCHITECTURAL DESIGN I\ HOUSE ELEVATION HEIGHTS EXAMPLE. This file gives you building height references.
2. Draw the elevations only to the level of detail shown in the image below. Include the Elevation Height Dimensions, Roof Slope Tags, and Overhang Dimensions and Title each elevation.
3. When complete print each of the elevations and each floor plan on a separate A-size sheet of paper, fit to paper, and turn in for review.

### EXAMPLE OF A "BLOCKED-OUT ELEVATION"

